






POCKET SECURE APP INSTRUCTIONS

Once installed on your phone you will be able to arm / disarm the system, check the status of the alarm and look at the system history review by pressing the "more info" (top right three dots icon) tab from anywhere in the world.



iPhone

1. Open  *App Store*. Search for "Pocket Secure", then press **\$1.49**.
2. Open  *Settings*. Select *Pocket Secure* then enter the email and password issued by Bellbond
3. Open  *Pocket Secure* from your home screen.

Android

1. Open  *Play Store*. Search for "Pocket Secure Permaconn", then press **Install**.
2. Open  *Pocket Secure* from your home screen. Then enter the email and password issued by Bellbond

Windows 8 Phone

1. Open  *Store*. Search for "Pocket Secure Permaconn", select the first result, then press **Buy**.
2. Open  *Pocket Secure* from your home screen. Then enter the email and password issued by Bellbond

ENABLING PIN NUMBER – HIGHLY RECOMMENDED – TO STOP ANYONE WITH ACCESS TO YOUR MOBILE DEVICE THAT MAY INADVERTANTLY ARM/DISARM YOUR ALARM

To do so:

1. Touch the three line icon at the top left of the screen,
2. Touch account
3. Enable PIN LOCK.
4. Enter PIN
5. Confirm PIN
6. You will have to exit the app to exit this screen.
7. Once you re-open the app
8. You will require a PIN to access the alarm controls. This is designed for additional security to arm and disarm your alarm system. The mobile device pin does not have to be the same as the code pad for the alarm panel.

